



**EDEA SOLE
MEASUREMENT
Millimeters**

**Frame
Length
(Based on the
Standard Mount)**

**Standard
Mount**



**Long
Mount**



**Short
Mount**



BOOT SIZE

BOOT SIZE	EDEA SOLE MEASUREMENT Millimeters	Frame Length (Based on the Standard Mount)	Standard Mount	Long Mount	Short Mount
185	183	180	90	90	90
190	183	180	90	90	90
195	189	190	100	100	90
200	189	190	100	100	90
205	195	190	110	110	100
210	195	200	110	110	100
215	205	200	110	110	110
220	205	200	110	110	110
225	218	210	120	130	120
230	218	210	120	130	120
235	226	220	130	130	120
240	226	220	130	130	120
245	236	230	140	140	140
250	236	230	140	140	140
255	249	240	150	160	140
260	249	240	150	160	140
265	253	250	160	170	150
270	253	250	160	170	150
275	266	260	170	170	160
280	266	260	170	170	160
285	272	260	170	180	160
290	272	260	170	180	160
295	283	270	180	190	170
300	283	270	180	190	170
305	292	280	190	200	180
310	292	280	190	200	180

Edea Sole Length
Tolerance 1%

Please note half
sizes available in
evo and killer only

Based on the Front
Axle at Ball of the
Foot.

Based on the longest sizes
possible-FreeStyle
Usually the front axle is
front of the ball or the foot

Based on the shortest sizes
possible-LoopFigures
Usually mount just a little
forward on the heel

As a General "Rule of Thumb", your EDEA Boot Size will be approximately 10mm (one (1) full size) larger than your actual Foot Measurement. There are personal preferences in how Skaters like boots to fit. Some like to actually feel the front of the Boot (but with NO Pressure), others want just a little extra room to wiggle the Toes, and yet others don't want to have a clue where the tip of the boot is (too much "Growth Room"). So Sizing is quite personal and varied.